

TOOLS NEEDED: $\frac{1}{16}$ " Or Adjustable Wrench
Phillips Head Screwdriver

PARTS INCLUDED: Top Shelf Assembly (A)
Bottom Shelf Assembly (B)
2 Front Legs (C)
2 Back Legs (D)
2 Side Support Braces (E)
Condiment Rack (F)
1 Back Support Brace (G)
1 Front Face Board (H)

HARDWARE: 12 - 3" Carriage Bolts
22 - 1 $\frac{1}{4}$ " Wood Screws
12 Washers
12 Nuts
4 Hooks



✳ ASSEMBLY TIP: For ease of assembly, finger tighten all fasteners first. Tighten securely after all parts are aligned. Do not over tighten. Holes are drilled to easily accept hardware. However, because of finish the holes may be tighter than normal. Lightly tapping the hardware with a hammer will help with the assembly. Using some soap on the screws will make the job a little easier.




1. Place the shelf assemblies on the floor so the ends with 2 pre-drilled holes are on the end that is upward. Attach a front leg to each assembly using (1) 3" carriage bolt, washer and nut on each side for each shelf.



2. Attach the back legs to the shelf assemblies using (2) 3" carriage bolts, washers and nuts on each side for each shelf



3. Attach support braces using (2) 1 $\frac{1}{4}$ " screws for each brace. See picture to the left for position of support braces. The brace should be flush with the front of the leg and the shelf.



4. Attach the brace to the back of the unit using (4) 1 $\frac{1}{4}$ " wood screws. The top of the brace should be flush with the support braces that you attached in step #3.



5. Attach face board to the front of the top shelf using (8) 1 $\frac{1}{4}$ " wood screws. The top of the face board should be flush with the top shelf.



6. Place rack on uprights. The front of the rack should be flush with the uprights. Attach using (3) 1 $\frac{1}{4}$ " screws on each side.

7. Tighten all hardware. Screw in the hooks where they are convenient for you.

CARE INSTRUCTIONS

Your new furniture requires very little maintenance. It may be washed with a mild detergent and water to remove surface dust and dirt. After prolonged exposure to the elements you may want to refinish it. We recommend lightly sanding it prior to refinishing, then use a cloth to remove the dust, refinish with a high quality exterior finish. It may be necessary at times to tighten the bolts and screws. It is normal for bolts to loosen somewhat in wood furniture. In northern climates, we recommend that the furniture be stored inside during the winter months.

LIMITED WARRANTY

This product is warranted only against defects in materials and workmanship for one year following the date of purchase. This limited warranty is in lieu of all other warranties, expressed or implied, and no one is authorized to assume for the company any other liability in connection with their sale of this product. This warranty gives you specific rights and you may also have other rights, which vary, from state to state.